

A.1 ASCII Code Table

The following are the ASCII codes for characters:

MSD LSD		0 0000	1 0001	2 0010	3 0011	4 0100	5 0101	6 0110	7 0111	8 1000	9 1001	A 1010	B 1011	C 1100	D 1101	E 1110	F 1111
0	0000			SP	O	@	P	☼	☒	}	—	q	n		⌋	—	□
1	0001	↓	!	!	A	Q	H	☒	☒	☒	a	/	☐	☐	♠	●	
2	0010	↑	"	2	B	R	I	☒	☐	e	z	ü	☐	☐	☐	☐	☐
3	0011	→	#	3	C	S	♣	☒	☐	`	w	m	☐	☐	☐	☐	♥
4	0100	←	\$	4	D	T	♣	☒	☐	~	s	☐	☐	☐	☐	☐	☐
5	0101	H	%	5	E	U	♣	☒	☐	☒	u	☐	☐	☐	☐	☐	☐
6	0110		C	&	6	F	V	☒	☐	t	i	☐	→	☐	☐	☐	☒
7	0111			'	7	G	W	☐	☐	g	=	o	☐	☐	☐	☐	○
8	1000			(	8	H	X	☐	☐	h	ö	l'	☐	☐	☐	☐	♣
9	1001			)	9	I	Y	☐	☐	☐	k	Ä	☐	☐	☐	☐	☐
A	1010			*	:	J	Z	☐	☐	b	f	ö	☐	☐	☐	☐	♦
B	1011			+	;	K	[	☐	°	^	x	v	ä	☐	☐	☐	£
C	1100			,	<	L	\	☐	☐	d	☐	☐	☐	☐	☐	☐	↓
D	1101	CR		—	=	M	]	☐	☐	r	ü	y	☐	☐	☐	☐	☐
E	1110			.	>	N	↑	☐	☐	p	β	{	☐	☐	☐	☐	☐
F	1111			/	?	O	←	☐	☐	c	j	☐	☐	☐	☐	☐	π

A.2 Display Code Table

The following are the display codes of the MZ-80A.

MSD \ LSD		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
		0000	0001	0010	0011	0100	0101	0110	0111	1000	1001	1010	1011	1100	1101	1110	1111
0	0000	SP	P	O	□	}	↑	π	□		p	□	□	↓	□	□	□
1	0001	A	Q	I	□	♠	<	!	□	a	q	□	□	↓	□	□	□
2	0010	B	R	2	□	□	□	"	□	b	r	□	□	↑	□	□	□
3	0011	C	S	3	□	♥	♥	#	□	c	s	□	□	→	□	□	□
4	0100	D	T	4	□	♦	□	\$	□	d	t	□	□	←	□	□	□
5	0101	E	U	5	□	←	@	%	□	e	u	□	□	H	□	□	□
6	0110	F	V	6	□	♣	□	&	□	f	v	□	□	□	□	□	□
7	0111	G	W	7	□	●	>	'	□	g	w	□	□	□	□	□	□
8	1000	H	X	8	□	○	↓	(	□	h	x	□	□	H	□	□	□
9	1001	I	Y	9	□	?	□	)	□	i	y	□	□	I	□	□	□
A	1010	J	Z	—	□	□	→	+	□	j	z	β	□	□	□	□	□
B	1011	K	£	=	□	□	□	*	□	k	ä	ü	□	□	□	□	□
C	1100	L	□	;	□	□	□	□	□	l	□	ö	□	□	□	□	□
D	1101	M	□	□	□	□	□	□	□	m	□	ü	□	□	□	□	□
E	1110	N	□	□	□	□	□	□	□	n	□	Ä	□	□	□	□	□
F	1111	O	□	□	□	□	□	□	□	o	□	Ö	□	□	□	□	□